

EXP NO: 12 Write a code using RAW sockets
10/10/25 to implement packet sniffing.
AIM: To implement a packet sniffer using
RAW sockets.

CODE:

```
from scapy.all import sniff
from scapy.layers.inet import IP, TCP, UDP
ICMP

def packet_callback(packet):
    if IP in packet:
        ip_layer = packet[IP]
        protocol = ip_layer.proto
        src_ip = ip_layer.src
        dst_ip = ip_layer.dst

        if protocol == 1:
            protocol_name = "ICMP"
        elif protocol == 6:
            protocol_name = "TCP"
        elif protocol == 17:
            protocol_name = "UDP"
        else:
            protocol_name = "Unknown Protocol"

        print(f"Protocol: {protocol_name}")
        print(f"Source IP: {src_ip}")
        print(f"Destination IP: {dst_ip}")
        print("-" * 50)

    sniff(iface='Wi-Fi', prn=packet_callback,
          filter="ip", store=0)
```

sample Input output

Protocol: TCP
Source IP: 192.168.1.10
Destination IP: 142.250.72.14

Protocol: ICMP
Source IP: 192.168.1.10
Destination IP: 8.8.8.8

Protocol: UDP
Source IP: 192.168.1.10
Destination IP: 192.168.1.1

- RESULT:
- * The packet sniffer successfully captures IP packets on the network, identifying their protocol type, source IP or destination IP.
 - * This demonstrates the use of raw socket for monitoring network traffic in real-time.

10/10
13Tx/12s

```
from scapy.all import sniff
from scapy.layers.inet import IP, TCP, UDP, ICMP

def packet_callback(packet):
    if IP in packet:
        ip_layer = packet[IP]
        protocol = ip_layer.proto
        src_ip = ip_layer.src
        dst_ip = ip_layer.dst

        # Determine the protocol
        protocol_name = ""
        if protocol == 1:
            protocol_name = "ICMP"
        elif protocol == 6:
            protocol_name = "TCP"
        elif protocol == 17:
            protocol_name = "UDP"
        else:
            protocol_name = "Unknown Protocol"

        # Print packet details
        print(f"Protocol: {protocol_name}")
        print(f"Source IP: {src_ip}")
        print(f"Destination IP: {dst_ip}")
        print("-" * 50)

    # Capture packets on the default network interface
    sniff(iface='Wi-Fi', prn=packet_callback, filter="ip", store=0)
```

C:\Users\tkala\Downloads>python packet.py

Protocol: TCP

Source IP: 57.155.141.117

Destination IP: 192.168.1.6

Protocol: TCP

Source IP: 192.168.1.6

Destination IP: 57.155.141.117

Protocol: TCP

Source IP: 192.168.1.6

Destination IP: 57.155.141.117

Protocol: TCP

Source IP: 192.168.1.6

Destination IP: 57.155.141.117

Protocol: TCP

Source IP: 57.155.141.117

Destination IP: 192.168.1.6

Protocol: TCP

Source IP: 57.155.141.117

Destination IP: 192.168.1.6

Protocol: UDP

Source IP: 192.168.1.6

Destination IP: 192.168.1.1

Protocol: UDP

Source IP: 192.168.1.6

Destination IP: 192.168.1.1

Protocol: UDP

Source IP: 192.168.1.6

Destination IP: 192.168.1.1

Protocol: UDP

Source IP: 192.168.1.1

Destination IP: 192.168.1.6